



## Quick Set Up Manual




The Eliminator Demon Drive Pedal gives you nearly endless adjustments to customize the feel to your exact preference. Start with the three basic settings below and fine tune the Beater Position, Footboard Angle, and Spring Tension to perfectly match your playing style. Refer to the included manual for the adjustment of each parts.



· For players seeking High Speed and Accuracy











FINESSE "A" POSITION



STANDARD POSITION




SHORT BOARD




STANDARD POSITION


# **POWER SETTING**

### · For players seeking Powerful Defined Tone











STANDARD POSITION




POWER "B" POSITION



ONE NOTCH BEFORE STANDARD POSITION




SHORT BOARD



ONE NOTCH ABOVE STANDARD POSITION


# LIGHT SETTING

### · For players seeking Light Feel with Power







LIGHT "L" POSITION



STANDARD POSITION




FINESSE "A" POSITION



STANDARD POSITION



LONG BOARD



TWO NOTCHES ABOVE STANDARD POSITION