



シンバルブームスタンド スペアパーツリスト



BC-2030	BC-890
B-1030	B-890
BC-930	BC-800W
BC-830	B-800W
BC-2000	B-790
BC-1030	BC-100S
B-1000	B-70W
BC-900	


BC-2030



			品番	税抜	税込	名称
A			*UB-BC203	7000	7700	Upper Boom Assy. Complete
A	1		*WL-230A	1500	1650	WingLoc Assy. Complete
A	1	A	*WL-230	1000	1100	WingLoc Quick Release Wing Nut w/Reversible Felt/Foam Washer
A	1	A	*FLW-006	400	440	Top Reversible Felt/Foam Washer
A	1	B	*FLW-005	650	715	Bottom Reversible Felt/Foam Washer
A	1	C	*RC-20	250	275	Reversible Seat Cup w/O-Ring
A	2		*DC-634AN	1300	1430	Clamp Assy. Complete
A	2	A	*UGB-620W	350	385	Die-Cast Wing Bolt w/Washer
A	2	B	*KB-620W	150	165	Key Bolt w/Washer
A	2	C	*DC-634N	800	880	Clamp Plate
A	3		*UGB-815P	350	385	Die-Cast Wing Bolt w/Pin
A	4		*DC-627AN	450	495	Stop Lock Complete (one set)
A	5		*ME-651N	800	880	Knurled Boom Arm
B			*LB-BC203	8000	8800	Lower Boom Assy. Complete
B	1		*BC-BC90	2600	2860	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SG-001	250	275	Spring

B	1	C	*ZD-018N	1100	1210	Clamp Gear Link
B	1	D	*ZD-019A	1000	1100	Boom Clamp Bolt
B	2		*DC-625A	450	495	Stop Lock Complete
B	2	A	*KB-615O	150	165	Key Bolt w/O-Ring
B	3		*NP-430	350	385	Plastic Tip
B	4		*NP-373A	3800	4180	Boom Arm Counterweight w/Key Bolt
B	4	A	*KB-615	150	165	Key Bolt
C			*UT-BC203	4000	4400	Upper Tube Assy. Complete
C	1		*BC-BC203	2600	2860	Boom Clamp Assy. Complete
C	1	A	*UGN-8L	500	550	Die-Cast Wing Nut w/Washer
C	1	B	*SG-007N	250	275	Spring
C	1	C	*ZD-129	1100	1210	Clamp Gear Link
C	1	D	*ZD-128A	1000	1100	Boom Clamp Bolt
C	2		*NP-375	250	275	Plastic Tip
D			*ZD-106A	800	880	Stop Lock Complete
D	1		*KB-625O	150	165	Key Bolt w/O-Ring
E			*CT-203	2600	2860	Center Tube Assy. Complete
E	1		PJ-100S	1700	1870	Die-Cast Joint Assy. Complete
E	1	A	*NP-367	200	220	Nylon Bushing
E	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
E	1	C	*SC-169	200	220	Clamp Bolt
E	2		*NP-376	250	275	Plastic Tip
F			*ZD-104A	800	880	Stop Lock Complete
F	1		*KB-625O	150	165	Key Bolt w/O-Ring
G			*BA-203	10000	11000	Base Assy. Complete
G	1		PJ-100L	2200	2420	Die-Cast Joint Assy. Complete
G	1	A	*NP-366	200	220	Nylon Bushing
G	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
G	1	C	*SC-169	200	220	Clamp Bolt
G	2		*UGB-815SW	350	385	Die-Cast Wing Bolt w/Washer
G	3		*DC-582A	800	880	Stop Lock Complete
G	3	A	*KB-625WO	150	165	Key Bolt w/Washer & O-Ring
G	4		*RB-001	450	495	Rubber Tip (one each)


B-1030



			品番	税抜	税込	名称
A			*AA-B103	5200	5720	Boom Assy. Complete
A	1		*WL-230A	1500	1650	WingLoc Assy. Complete
A	1	A	*WL-230	1000	1100	WingLoc Quick Release Wing Nut w/Reversible Felt/Foam Washer
A	1	A 1	*FLW-006	400	440	Top Reversible Felt/Foam Washer
A	1	B	*FLW-005	650	715	Bottom Reversible Felt/Foam Washer
A	1	C	*RC-20	250	275	Reversible Seat Cup w/O-Ring
A	2		*UGB-815P	350	385	Die-Cast Wing Bolt w/Pin
A	3		*DC-625A	450	495	Stop Lock Complete
A	3	A	*KB-6150	150	165	Key Bolt w/O-Ring
A	4		*NP-71	250	275	Plastic Tip
B			*UT-B103	4000	4400	Upper Tube Assy. Complete
B	1		*BC-BC203	2600	2860	Boom Clamp Assy. Complete
B	1	A	*UGN-8L	500	550	Die-Cast Wing Nut w/Washer
B	1	B	*SG-007N	250	275	Spring
B	1	C	*ZD-129	1100	1210	Clamp Gear Link
B	1	D	*ZD-128A	1000	1100	Boom Clamp Bolt
B	2		*NP-375	250	275	Plastic Tip
C			*CT-103	2600	2860	Center Tube Assy. Complete
C	1		PJ-100S	1700	1870	Die-Cast Joint Assy. Complete
C	1	A	*NP-367	200	220	Nylon Bushing
C	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
C	1	C	*SC-169	200	220	Clamp Bolt


C	2			*NP-376	250	275	Plastic Tip
D				*BA-103	9500	10450	Base Assy. Complete
D	1			PJ-100L	2200	2420	Die-Cast Joint Assy. Complete
D	1	A		*NP-366	200	220	Nylon Bushing
D	1	B		*UGN-6	300	330	Die-Cast Wing Nut w/Washer
D	1	C		*SC-169	200	220	Clamp Bolt
D	2			*UGB-815SW	350	385	Die-Cast Wing Bolt w/Washer
D	3			*RB-001	450	495	Rubber Tip (one each)

BC-930




			品番	税抜	税込	名称
A			*AA-BC90	3700	4070	Boom Assy. Complete
A	1		*UTS-93	800	880	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-001	200	220	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*UGB-830W	350	385	Die-Cast Wing Bolt w/Washer
B			*UT-BC89	3800	4180	Upper Tube Assy. Complete
B	1		*BC-BC90	2600	2860	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SG-001	250	275	Spring
B	1	C	*ZD-018N	1100	1210	Clamp Gear Link
B	1	D	*ZD-019A	1000	1100	Boom Clamp
C			*CT-93	2400	2640	Boom Clamp Bolt
C	1		PJ-100S	1700	1870	Center Tube Assy. Complete
C	1	A	*NP-367	200	220	Die-Cast Joint Assy. Complete
C	1	B	*UGN-6	300	330	Die-Cast Wing Bolt
C	1	C	*SC-169	200	220	Allen Screw
D			*BA-93	7800	8580	Base Assy. Complete
D	1		PJ-100L	2200	2420	Die-Cast Joint Assy. Complete
D	1	A	*NP-366	200	220	Die-Cast Wing Bolt
D	1	B	*UGN-6	300	330	Allen Screw
D	1	C	*SC-169	200	220	Die-Cast Wing Bolt
D	2		*UGB-815S	300	330	
D	3		*RB-008	400	440	Rubber Tip (one each)

BC-830



			品番	税抜	税込	名称
A			*AA-BC83	3500	3850	Boom Assy. Complete
A	1		*UTS-83	700	770	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*UGB-830TW	350	385	Die-Cast Wing Bolt w/Washer
B			*UT-BC83	3800	4180	Upper Tube Assy. Complete
B	1		*BC-BC83	2600	2860	Boom Clamp Assy. Complete
B	1	A	*UGN-8T	350	385	Die-Cast Wing Nut w/Washer
B	1	B	*SG-001	250	275	Spring
B	1	C	*ZD-118	1000	1100	Clamp Gear Link
B	1	D	*ZD-119	1000	1100	Boom Clamp
B	1	E	*SC-471	250	275	Boom Clamp Bolt
C			*CT-83	2000	2200	Center Tube Assy. Complete
C	1		PJ-83S	1300	1430	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815S	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
D			*BA-83	5000	5500	Base Assy. Complete
D	1		PJ-83L	1800	1980	Die-Cast Joint Assy. Complete
D	1	A	*UGB-815S	350	385	Die-Cast Wing Bolt
D	1	B	*SB-44	100	110	Allen Screw
D	2		*UGB-815S	350	385	Die-Cast Wing Bolt
D	3		*RB-022	300	330	Rubber Tip (one each)


BC-2000



			品番	税抜	税込	名称
A			*B-200A	6200	6820	Upper Boom Assy. Complete
A	1		*WL-200A	1000	1100	WingLoc Assy. Complete
A	1	A	*WL-200	800	880	WingLoc Quick Release Wing Nut w/Felt
A	1	B	*FLW-001	200	220	Felt (one each)
A	1	C	*RC-20	250	275	Reversible Seat Cup w/O-Ring
A	2		*DC-634A	1200	1320	Clamp Assy. Complete (~2005/12)
A	2'		*DC-634AN	1300	1430	Clamp Assy. Complete (2006/1~)
A	2	A	*UGB-620	350	385	Die-Cast Wing Bolt w/Washer
A	2	B	*KB-620W	150	165	Key Bolt w/Washer
A	2	C	*DC-634	800	880	Clamp Plate (~2005/12)
A	2	C'	*DC-634N	800	880	Clamp Plate (2006/1~)
A	3		*UGB-815P	350	385	Die-Cast Wing Bolt w/Pin
A	4		*DC-627A	350	385	Stop Lock, Complete (~2005/12)
A	4'		*DC-627AN	450	495	Stop Lock, Complete (2006/1~)
A	4	A	*KB-615WO	150	165	Key Bolt w/Washer
A	5		*ME-651	600	660	Knurled Boom Arm
B			*B-200B	4500	4950	Lower Boom Assy. Complete
B	1		*BC-200A	2400	2640	Boom Clamp Assy. Complete
B	1'		*BC-200AN	2400	2640	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*DC-630	1000	1100	Clamp Gear Link
B	1	B'	*DC-630N	100	110	Clamp Gear Link
B	1	C	*SG-001	250	275	Spring
B	1	D	*DC-595A	1000	1100	Boom Clamp Bolt

B	2			*DC-625A	450	495	Stop Lock, Complete
B	2	A		*KB-615WO	150	165	Key Bolt w/Washer
B	3			*NP-430	350	385	Plastic Tip
B	4			*NP-373A	3800	4180	Boom Arm Counterweight
B	4	A		*KB-615	150	165	Key Bolt
C				*TU-100A	4000	4400	Upper Tube Assy. Complete
C	1			*BC-100A	2600	2860	Boom Clamp Assy. Complete
C	1	A		*UGN-8L	500	550	Die-Cast Wing Nut w/Washer
C	1	B		*SP-27N	250	275	Spring
C	1	C		*DC-594	1000	1100	Clamp Gear Link
C	1	D		*DC-596A	1000	1100	Boom Clamp Bolt
C	2			*NP-375	250	275	Plastic Tip
D				*DC-578A	800	880	Stop Lock Complete
D	1			*KB-625WO	150	165	Key Bolt w/Washers
E				*CP-100A	2400	2640	Center Tube Assy. Complete
E	1			DJ-500	1700	1870	Die-Cast Joint Assy. Complete
E	1	A		*NP-367	200	220	Nylon Bushing
E	1	B		*UGN-6	300	330	Die-Cast Wing Nut w/Washer
E	1	C		*SC-169	200	220	Clamp Bolt
E	2			*NP-376	250	275	Plastic Tip
F				*DC-576A	800	880	Stop Lock Complete
F	1			*KB-625WO	150	165	Key Bolt w/Washers
G				*BA-200BW	8000	8800	Base Assy. Complete
G	1			DJ-700	2200	2420	Die-Cast Joint Assy. Complete
G	1	A		*NP-366	200	220	Nylon Bushing
G	1	B		*UGN-6	300	330	Die-Cast Wing Nut w/Washer
G	1	C		*SC-169	200	220	Clamp Bolt
G	2			*UGB-815	350	385	Die-Cast Wing Bolt
G	3			*DC-582A	800	880	Stop Lock Complete
G	3	A		*KB-625WO	150	165	Key Bolt w/Washers
G	4			R-22N	350	385	Rubber Tip


BC-1030



			品番	税抜	税込	名称
A			*AA-BC103	4600	5060	Boom Assy. Complete
A	1		*WL-230A	1500	1650	WingLoc Assy. Complete
A	1	A	*WL-230	1000	1100	WingLoc Quick Release Wing Nut w/Reversible Felt/Foam Washer
A	1	A 1	*FLW-006	400	440	Top Reversible Felt/Foam Washer
A	1	B	*FLW-005	650	715	Bottom Reversible Felt/Foam Washer
A	1	C	*RC-20	250	275	Reversible Seat Cup w/O-Ring
A	2		*UGB-815P	350	385	Die-Cast Wing Bolt w/Pin
A	3		*DC-627AN	450	495	Stop Lock Complete
A	3	A	*KB-615O	150	165	Key Bolt w/O-Ring
B			*UT-BC103	4000	4400	Upper Tube Assy. Complete
B	1		*BC-BC90	2600	2860	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SG-001	250	275	Spring
B	1	C	*ZD-018N	1100	1210	Clamp Gear Link
B	1	D	*ZD-019A	1000	1100	Boom Clamp Bolt
B	2		*NP-375	250	275	Plastic Tip
C			*CT-103	2600	2860	Center Tube Assy. Complete
C	1		PJ-100S	1700	1870	Die-Cast Joint Assy. Complete
C	1	A	*NP-367	200	220	Nylon Bushing
C	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
C	1	C	*SC-169	200	220	Clamp Bolt
C	2		*NP-376	250	275	Plastic Tip


D				*BA-103	9500	10450	Base Assy. Complete
D	1			PJ-100L	2200	2420	Die-Cast Joint Assy. Complete
D	1	A		*NP-366	200	220	Nylon Bushing
D	1	B		*UGN-6	300	330	Die-Cast Wing Nut w/Washer
D	1	C		*SC-169	200	220	Clamp Bolt
D	2			*UGB-815SW	350	385	Die-Cast Wing Bolt w/Washer
D	3			*RB-001	450	495	Rubber Tip (one each)

B-1000




			品番	税抜	税込	名称
A			*B-100A	3700	4070	Boom Assy. Complete
A	1		*WL-200A	1000	1100	WingLoc Assy. Complete
A	1	A	*WL-200	800	880	WingLoc Quick Release Wing Nut w/Felt
A	1	B	*FLW-001	200	220	Felt (one each)
A	1	C	*RC-20	250	275	Reversible Seat Cup w/O-Ring
A	2		*UGB-815P	350	385	Die-Cast Wing Bolt w/Pin
A	3		*DC-625A	450	495	Stop Lock, Complete
A	3	A	*KB-615WO	150	165	Key Bolt
A	4		*NP-71	250	275	Rubber Tip
B			*TU-100A	4000	4400	Upper Tube Assy. Complete
B	1		*BC-100A	2600	2860	Boom Clamp Assy. Complete
B	1	A	*UGN-8L	500	550	Die-Cast Wing Nut w/Washer
B	1	B	*SP-27N	250	275	Spring
B	1	C	*DC-594	1000	1100	Clamp Gear Link
B	1	D	*DC-596A	1000	1100	Boom Clamp Bolt
B	2		*NP-375	250	275	Plastic Tip
C			*CP-100A	2400	2640	Center Tube Assy. Complete
C	1		DJ-500	1700	1870	Die-Cast Joint Assy. Complete
C	1	A	*NP-367	200	220	Nylon Bushing
C	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
C	1	C	*SC-169	200	220	Clamp Bolt
C	2		*NP-376	250	275	Plastic Tip
D			*BA-100BW	7500	8250	Base Assy. Complete
D	1		DJ-700	2200	2420	Die-Cast Joint Assy. Complete
D	1	A	*NP-366	200	220	Nylon Bushing
D	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
D	1	C	*SC-169	200	220	Clamp Bolt
D	2		*UGB-815	350	385	Die-Cast Wing Bolt
D	3		R-22N	350	385	Rubber Tip

BC-900




			品番	税抜	税込	名称
A			*AA-BC90	3700	4070	Boom Assy. Complete
A	1		*UTS-93	800	880	WingLoc Assy. Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-001	200	220	Felt (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*UGB-830W	350	385	Die-Cast Wing Bolt w/Washer
B			*UT-BC90	4000	4400	Upper Tube Assy. Complete
B	1		*BC-BC90	2600	2860	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SG-001	250	275	Spring
B	1	C	*ZD-018N	1100	1210	Clamp Gear Link
B	1	D	*ZD-019A	1000	1100	Boom Clamp Bolt
B	2		*ZD-075A	350	385	Stop Lock, Complete
B	2	A	*KB-620	150	165	Key Bolt
C			*CT-90	2400	2640	Center Tube Assy. Complete
C	1		PJ-90S	1700	1870	Die-Cast Joint Assy. Complete
C	1	A	*UGN-6C	300	330	Die-Cast Wing Nut w/Collar
C	1	B	*PL-009	200	220	Nylon Bushing
C	1	C	*SC-392	200	220	Clamp Bolt
C	2		*ZD-024A	350	385	Stop Lock, Complete
C	2	A	*KB-625	150	165	Key Bolt
D			*BA-90	7800	8580	Base Assy. Complete
D	1		PJ-90L	2200	2420	Die-Cast Joint Assy. Complete
D	1	A	*UGN-6C	300	330	Die-Cast Wing Nut w/Collar
D	1	B	*PL-008	200	220	Nylon Bushing
D	1	C	*SC-392	200	220	Clamp Bolt
D	2		*UGB-815	350	385	Die-Cast Wing Bolt
D	3		*RB-008	400	440	Rubber Tip (one each)

BC-890




			品番	税抜	税込	名称
A			*AA-BC89	3000	3300	Boom Assy. Complete
A	1		*UTS-93	800	880	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-001	200	220	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*SN-800A	500	550	Bolt & Nut Set w/Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
A	2	B	*SG-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-890	1000	1100	Tilter Unit
B			*UT-BC89	3800	4180	Upper Tube Assy. Complete
B	1		*BC-BC90	2600	2860	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SG-001	250	275	Spring
B	1	C	*ZD-018N	1100	1210	Clamp Gear Link
B	1	D	*ZD-019A	1000	1100	Boom Clamp Bolt
C			*CT-89	2000	2200	Center Tube Assy. Complete
C	1		*DJ-55A	1300	1430	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
D			*BA-89	7800	8580	Base Assy. Complete
D	1		DJ-75A	1800	1980	Die-Cast Joint Assy. Complete
D	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
D	1	B	*SB-44	100	110	Allen Screw
D	2		*UGB-815	350	385	Die-Cast Wing Bolt
D	3		*RB-008	400	440	Rubber Tip (one each)

B-890




			品番	税抜	税込	名称
A			*AA-B89	2800	3080	Boom Assy. Complete
A	1		*UTS-93	800	880	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-001	200	220	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*SN-800A	500	550	Bolt & Nut Set w/Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
A	2	B	*SG-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-890	1000	1100	Tilter Unit
A	4		*ZD-016A	400	440	Stop Lock Complete
A	4	A	*KB-620	150	165	Key Bolt
A	5		*NP-71	250	275	Plastic Tip
B			*UT-B89	3800	4180	Upper Tube Assy. Complete
B	1		*BC-B90	2400	2640	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SP-27	250	275	Spring
B	1	C	*ZD-014	1000	1100	Clamp Gear Link
B	1	D	*ZD-015A	1000	1100	Boom Clamp Bolt
C			*CT-89	2000	2200	Center Tube Assy. Complete
C	1		DJ-55A	1300	1430	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
D			*BA-89	7800	8580	Base Assy. Complete
D	1		DJ-75A	1800	1980	Die-Cast Joint Assy. Complete
D	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
D	1	B	*SB-44	100	110	Allen Screw
D	2		*UGB-815	350	385	Die-Cast Wing Bolt
D	3		*RB-008	400	440	Rubber Tip (one each)

BC-800W




			品番	税抜	税込	名称
A			*ME-521AC	3000	3300	Boom Arm Assy. Complete
A	1		*FL-80AN	600	660	Upper Tilter Section Complete
A	1	A	*M-8W	300	330	Die-Cast Wing Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*NP-70	150	165	Plastic Sleeve
A	1	D	*PR-135	150	165	Cup Washer
A	2		*SN-800A	500	550	Bolt & Nut Set w/ Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/ Washer
A	2	B	*SG-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-800N	1000	1100	Tilter Unit
B			*TU-80BC	3800	4180	Upper Tube Assy. Complete
B	1		*BC-80BC	2400	2640	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/ Washer
B	1	B	*SG-001	250	275	Spring
B	1	C	*DC-530	1000	1100	Clamp Gear Link
B	1	D	*DC-529A	1000	1100	Boom Clamp Bolt
C			*PP-149BA	2000	2200	Center Tube Assy. Complete
C	1		DJ-55A	1300	1430	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
D			*BA-800BW	7800	8580	Base Assy. Complete
D	1		DJ-75A	1800	1980	Die-Cast Joint Assy. Complete
D	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
D	1	B	*SB-44	100	110	Allen Screw
D	2		*UGB-815	350	385	Die-Cast Wing Bolt
D	3		R-22N	350	385	Rubber Tip

B-800W




			品番	税抜	税込	名称
A			*PP-169ACN	2800	3080	Boom Arm Assy. Complete
A	1		*FL-80AN	600	660	Upper Tilter Section Complete
A	1	A	*M-8W	300	330	Die-Cast Wing Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*NP-70	150	165	Plastic Sleeve
A	1	D	*PR-135	150	165	Cup Washer
A	2		*SN-800A	500	550	Bolt & Nut Set w/Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
A	2	B	*SG-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-800N	1000	1100	Tilter Unit
A	4		-			Stop Lock, Complete
A	4	A	*KB-620	150	165	Key Bolt
A	5		*NP-71	250	275	Plastic Tip
B			*TU-800A	3800	4180	Upper Tube Assy. Complete
B	1		*BC-800A	2400	2640	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SP-27N	250	275	Spring
B	1	C	*DC-371	1000	1100	Clamp Gear Link
B	1	D	*BTL-85N	1000	1100	Boom Clamp Bolt
C			*PP-149BA	2000	2200	Center Tube Assy. Complete
C	1		DJ-55A	1300	1430	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
D			*BA-800BW	7800	8580	Base Assy. Complete
D	1		DJ-75A	1800	1980	Die-Cast Joint Assy. Complete
D	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
D	1	B	*SB-44	100	110	Allen Screw
D	2		*UGB-815	350	385	Die-Cast Wing Bolt
D	3		R-22N	350	385	Rubber Tip

B-790




			品番	税抜	税込	名称
A			*AA-B79	2200	2420	Boom Assy. Complete
A	1		*UTS-83	700	770	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*SN-800A	500	550	Bolt & Nut Set w/ Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/ Wahser
A	2	B	*SQ-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-890	1000	1100	Tilter Unit
A	4		*NP-71	250	275	Plastic Tip
B			*UT-B79	3200	3520	Upper Tube Assy. Complete
B	1		*BC-B79	1750	1925	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/ Washer
B	1	B	*SP-27	250	275	Spring
B	1	C	*ZD-084	800	880	Clamp Gear Link
B	1	D	*ZD-086A	500	550	Boom Clamp Bolt
C			*BA-79	5000	5500	Base Assy. Complete
C	1		DJ-07A	1100	1210	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815A	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
C	2		*UGB-815A	350	385	Die-Cast Wing Bolt
C	3		*PL-034	350	385	Rubber Tip (one each)

BC-100S



			品番	税抜	税込	名称
A			*ME-716AC	3000	3300	Boom Assy. Complete
A	1		*FL-100AN	600	660	Upper Tilter Section Complete
A	1	A	*M-8W	300	330	Die-Cast Wing Nut
A	1	B	*FE-18	200	220	Felt Washer (one each)
A	1	C	*NP-70	150	165	Plastic Sleeve
A	1	D	*PR-135	150	165	Cup Washer
A	2		*SN-800A	500	550	Bolt & Nut Set w/Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
A	2	B	*SG-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-800N	1000	1100	Tilter Unit
B			*TU-80BCL	3800	4180	Upper Tube Assy. Complete
B	1		*BC-80BC	2400	2640	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SG-001	250	275	Spring
B	1	C	*DC-530	1000	1100	Clamp Gear Link
B	1	D	*DC-529A	1000	1100	Boom Clamp Bolt
C			*BA-100S	6000	6600	Base Assy. Complete
C	1		DJ-06A	1100	1210	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
C	2		*UGB-815	350	385	Die-Cast Wing Bolt
C	3		*NP-454	300	330	Rubber Tip (one each)

B-70W



			品番	税抜	税込	名称
A			*PP-605A	2200	2420	Boom Arm Assy. Complete
A	1		*FL-80AN	600	660	Upper Tilter Section Complete
A	1	A	*M-8W	300	330	Die-Cast Wing Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*NP-70	150	165	Plastic Sleeve
A	1	D	*PR-135	150	165	Cup Washer
A	2		*SN-800A	500	550	Bolt & Nut Set w/Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/Wahser
A	2	B	*SP-27N	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-800N	1000	1100	Tilter Unit
A	4		*NP-71	250	275	Plastic Cup
B			*PP-604A	3200	3520	Upper Tube Assy. Complete
B	1		*BC-07A	1750	1925	Boom Clamp Assy. Complete
B	1	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*SP-27N	250	275	Spring
B	1	C	*DC-606A	800	880	Clamp Gear Link
B	1	D	*DC-607A	500	550	Boom Clamp Bolt
C			*PP-603A	5000	5500	Base Assy. Complete
C	1		DJ-07A	1100	1210	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815A	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
C	2		*UGB-815	350	385	Die-Cast Wing Bolt
C	3		*NP-604	350	385	Rubber Tip