

シンバルスタンド スペアパーツリスト

C-1030

C-930

C-830

C-150S

C-1000


C-900

C-890


C-800W

C-790

C-70W




C-1030



			品番	税抜	税込	名称
A			*UT-C103	5300	5830	Upper Tube Assy. Complete
A	1		*WL-230A	1500	1650	WingLoc Assy. Complete
A	1	A	*WL-230	1000	1100	WingLoc Quick Release Wing Nut w/Reversible Felt/Foam Washer
A	1	A 1	*FLW-006	400	440	Top Reversible Felt/Foam Washer
A	1	B	*FLW-005	650	715	Bottom Reversible Felt/Foam Washer
A	1	C	*RC-20	250	275	Reversible Seat Cup w/O-Ring
A	2		*UGB-815P	350	385	Die-Cast Wing Bolt w/Pin
A	3		*NP-375	250	275	Plastic Tip
B			*CT-103	2600	2860	Center Tube Assy. Complete
B	1		PJ-100S	1700	1870	Die-Cast Joint Assy. Complete
B	1	A	*NP-367	200	220	Nylon Bushing
B	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
B	1	C	*SC-169	200	220	Clamp Bolt
B	2		*NP-376	250	275	Plastic Tip


C			*BA-103	9500	10450	Base Assy. Complete
C	1		PJ-100L	2200	2420	Die-Cast Joint Assy. Complete
C	1	A	*NP-366	200	220	Nylon Bushing
C	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
C	1	C	*SC-169	200	220	Clamp Bolt
C	2		*UGB-815SW	350	385	Die-Cast Wing Bolt w/Washer
C	3		*RB-001	450	495	Rubber Tip (one each)

C-930




			品番	税抜	税込	名称
A			*UT-C93	3500	3850	Upper Tube Assy. Complete
A	1		*UTS-93	800	880	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-001	200	220	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*UGB-830W	350	385	Die-Cast Wing Bolt w/Washer
B			*CT-93	2400	2640	Center Tube Assy. Complete
B	1		PJ-100S	1700	1870	Die-Cast Joint Assy. Complete
B	1	A	*NP-367	200	220	Nylon Bushing
B	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
B	1	C	*SC-169	200	220	Clamp Bolt
C			*BA-93	7800	8580	Base Assy. Complete
C	1		PJ-100L	2200	2420	Die-Cast Joint Assy. Complete
C	1	A	*NP-366	200	220	Nylon Bushing
C	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
C	1	C	*SC-169	200	220	Clamp Bolt
C	2		*UGB-815S	350	385	Die-Cast Wing Bolt
C	3		*RB-008	400	440	Rubber Tip (one each)

C-830




			品番	税抜	税込	名称
A			*UT-C83	3300	3630	Upper Tube Assy. Complete
A	1		*UTS-83	700	770	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*UGB-830TW	350	385	Die-Cast Wing Bolt w/Washer
B			*CT-83	2000	2200	Center Tube Assy. Complete
B	1		PJ-83S	1300	1430	Die-Cast Joint Assy. Complete
B	1	A	*UGB-815S	350	385	Die-Cast Wing Bolt
B	1	B	*SB-44	100	110	Allen Screw
C			*BA-83	5000	5500	Base Assy. Complete
C	1		PJ-83L	1800	1980	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815S	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
C	2		*UGB-815S	350	385	Die-Cast Wing Bolt
C	3		*RB-022	300	330	Rubber Tip (one each)

C-150S




			品番	税抜	税込	名称
A			*UT-C15S	3500	3850	Upper Tube Assy. Complete
A	1		*UTS-15S	1250	1375	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-006	400	440	Top Reversible Felt/Foam Washer
A	1	C	*FLW-005	650	715	Bottom Reversible Felt/Foam Washer
A	1	D	*PL-011	300	330	Cymbal Seat Cup
A	2		*UGB-830TW	350	385	Die-Cast Wing Bolt w/Washer
B			*CT-C15S	2000	2200	Center Tube Assy. Complete
B	1		PJ-45	1100	1210	Die-Cast Joint Assy. Complete
B	1	A	*UGB-815S	350	385	Die-Cast Wing Bolt
B	1	B	*SB-44	100	110	Allen Screw
C			*BA-C15S	5500	6050	Base Assy. Complete
C	1		PJ-60	1300	1430	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815S	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
C	2		*UGB-815S	350	385	Die-Cast Wing Bolt
C	3		*KB-814	150	165	Key Bolt
C	4		*NP-454N	500	550	Rubber Tip (one each)

C-1000




			品番	税抜	税込	名称
A			*C-100A	2600	2860	Upper Tube Assy. Complete
A	1		*WL-200A	1000	1100	WingLoc Assy. Complete
A	1	A	*WL-200	800	880	WingLoc Quick Release Wing Nut w/Felt
A	1	B	*FLW-001	200	220	Felt (one each)
A	1	C	*RC-20	250	275	Reversible Seat Cup w/O-Ring
A	2		*UGB-815P	350	385	Die-Cast Wing Bolt w/Pin
B			*CP-100A	2400	2640	Center Tube Assy. Complete
B	1		DJ-500	1700	1870	Die-Cast Joint Assy. Complete
B	1	A	*NP-367	200	220	Nylon Bushing
B	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
B	1	C	*SC-169	200	220	Clamp Bolt
B	2		*NP-376	250	275	Plastic Tip
C			*BA-100BW	7500	8250	Base Assy. Complete
C	1		DJ-700	2200	2420	Die-Cast Joint Assy. Complete
C	1	A	*NP-366	200	220	Nylon Bushing
C	1	B	*UGN-6	300	330	Die-Cast Wing Nut w/Washer
C	1	C	*SC-169	200	220	Clamp Bolt
C	2		*UGB-815	350	385	Die-Cast Wing Bolt
C	3		R-22N	350	385	Rubber Tip

C-900




			品番	税抜	税込	名称
A			*UT-C90	3800	4180	Upper Tube Assy. Complete
A	1		*UTS-93	800	880	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-001	200	220	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*UGB-830W	350	385	Die-Cast Wing Bolt w/Washer
A	3		*ZD-075A	350	385	Stop Lock, Complete
A	3	A	*KB-620	150	165	Key Bolt
B			*CT-90	2400	2640	Center Tube Assy. Complete
B	1		*PJ-90S	1700	1870	Die-Cast Joint Assy. Complete
B	1	A	*UGN-6C	300	330	Die-Cast Wing Nut w/Washer
B	1	B	*PL-009	200	220	Nylon Bushing
B	1	C	*SC-392	200	220	Clamp Bolt
B	2		*ZD-024A	350	385	Stop Lock, Complete
B	2	A	*KB-625	150	165	Key Bolt
C			*BA-90	7800	8580	Base Assy. Complete
C	1		PJ-90L	2200	2420	Die-Cast Joint Assy. Complete
C	1	A	*UGN-6C	300	330	Die-Cast Wing Nut w/Collar
C	1	B	*PL-008	200	220	Nylon Bushing
C	1	C	*SC-392	200	220	Clamp Bolt
C	2		*UGB-815	350	385	Die-Cast Wing Bolt
C	3		*RB-008	400	440	Rubber Tip (one each)

C-890




			品番	税抜	税込	名称
A			*UT-C89	2800	3080	Upper Tube Assy. Complete
A	1		*UTS-93	800	880	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-001	200	220	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*SN-800A	500	550	Bolt & Nut Set w/ Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/ Washer
A	2	B	*SG-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-890	1000	1100	Tilter Unit
B			*CT-89	2000	2200	Center Tube Assy. Complete
B	1		DJ-55A	1300	1430	Die-Cast Joint Assy. Complete
B	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
B	1	B	*SB-44	100	110	Allen Screw
C			*BA-89	7800	8580	Base Assy. Complete
C	1		DJ-75A	1800	1980	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
C	2		*UGB-815	350	385	Die-Cast Wing Bolt
C	3		*RB-008	400	440	Rubber Tip (one each)

C-800W




			品番	税抜	税込	名称
A			*C-80AN	2800	3080	Upper Tube Assy. Complete
A	1		*FL-80AN	600	660	Upper Tilter Section Complete
A	1	A	*M-8W	300	330	Die-Cast Wing Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*NP-70	150	165	Plastic Sleeve
A	1	D	*PR-135	150	165	Cup Washer
A	2		*SN-800A	500	550	Bolt & Nut Set w/Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
A	2	B	*SG-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-800N	1000	1100	Tilter Unit
B			*PP-149BA	2000	2200	Center Tube Assy. Complete
B	1		*DJ-55A	1300	1430	Die-Cast Joint Assy. Complete
B	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
B	1	B	*SB-44	100	110	Allen Screw
C			*BA-800BW	7800	8580	Base Assy. Complete
C	1		DJ-75A	1800	1980	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
C	2		*UGB-815	350	385	Die-Cast Wing Bolt
C	3		R-22N	350	385	Rubber Tip

C-790



			品番	税抜	税込	名称
A			UT-C79	2800	3080	Upper Tube Assy. Complete
A	1		UTS-83	700	770	Upper Tilter Section Complete
A	1	A	*PL-010	300	330	Plastic Cymbal Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*PL-011	300	330	Cymbal Seat Cup
A	2		*SN-800A	500	550	Bolt & Nut Set w/Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/Washer
A	2	B	*SG-001	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-890	1000	1100	Tilter Unit
B			*BA-79	5000	5500	Base Assy. Complete
B	1		DJ-07A	1100	1210	Die-Cast Joint Assy. Complete
B	1	A	*UGB-815A	350	385	Die-Cast Wing Bolt
B	1	B	*SB-44	100	110	Allen Screw
B	2		*UGB-815A	350	385	Die-Cast Wing Bolt
B	3		*PL-034	350	385	Rubber Tip (one each)

C-70W



			品番	税抜	税込	名称
A			*PP-608A	1800	1980	Upper Tube Assy. Complete
A	1		*FL-80AN	600	660	Upper Tilter Section Complete
A	1	A	*M-8W	300	330	Die-Cast Wing Nut
A	1	B	*FLW-004	150	165	Felt Washer (one each)
A	1	C	*NP-70	150	165	Plastic Sleeve
A	1	D	*PR-135	150	165	Cup Washer
A	2		*SN-800A	500	550	Bolt & Nut Set w/ Spring
A	2	A	*UGN-8	300	330	Die-Cast Wing Nut w/ Washer
A	2	B	*SP-27N	250	275	Spring
A	2	C	*SC-36B-ED	250	275	Clamp Bolt
A	3		*SN-800N	1000	1100	Tilter Unit
B			*PP-607A	1500	1650	Center Tube Assy. Complete
B	1		DJ-06A	1100	1210	Die-Cast Joint Assy. Complete
B	1	A	*UGB-815A	350	385	Die-Cast Wing Bolt
B	1	B	*SB-44	100	110	Allen Screw
C			*PP-606A	5000	5500	Base Assy. Complete
C	1		DJ-07A	1100	1210	Die-Cast Joint Assy. Complete
C	1	A	*UGB-815A	350	385	Die-Cast Wing Bolt
C	1	B	*SB-44	100	110	Allen Screw
C	2		*UGB-815	350	385	Die-Cast Wing Bolt
C	3		*NP-604	350	385	Rubber Tip